

Rosewill RK650
SLIM-SERIES KEYBOARD

User's Manual

Thank you for purchasing a quality Rosewill Product.
Please register your product at : www.rosewill.com/ for complete warranty information and future support for your product.

System Requirements

- » IBM or compatible PC
- » Windows operating system
- » Pentium or equivalent processor and above
- » One available USB port

OS Support

- » Windows 98/SE/ME
- » Windows 2000/NT
- » Windows XP

Introduction

Congratulations on your new purchase of the RK-650 *Elegance-Series* keyboard . For your personal enjoyment and safety, we recommend that you read through this manual thoroughly before using this product and keep this manual handy for reference if needed.

Contents in this package

The following items are included in the package. Please make sure all items are accounted for as you open the package. If there was any item(s) missing or damaged, please contact the reseller where the product was purchased or our support center for further assistance.

ITEMS


- » USB Keyboard
- » User's manual

Specification

- » Dimensions: 430.7x157.6x14.2mm
- » Weight: 515g
- » Interface: USB
- » Layout: US Standard 104-keys
- » Hot Keys: 5 Keys-Mute; Vol Down; Vol Up; Play/Pause; Stop.

Hot Key Functions

- » Mute Toggle mute ON/OFF
- » Vol.Up Turn up the volume
- » Vol.Down Turn down the volume
- » Play/Pause Toggle Play/Pause of current media
- » Stop Stop the currently playing media



Installation

This is a PnP (Plug-n-Play) device and compatible with Windows 98 SE and or later editions. A driver may be required when using the hotkey function of this device under Windows 98SE, ME, 2000 and NT; a driver is not needed for Windows XP. To locate the proper software for this product, please contact the respective authorized dealer for more information.

Warning

Some experts believe that prolonged-usage of keyboard or mouse may cause serious injury to hands, wrists, arms, neck or back. If you feel pain, fatigue, numbness and/or weakness in these areas, please see a qualified health professional for assistance. To reduce the risks of such injuries, we recommend that you:

- » Take frequent short-break from operating a computer or related tasks.
- » Avoid operating a computer for extended period of time; defined by each sittings of an hour or more.
- » Please consult with your family physician for the guideline on proper typing postures.

Do not use this product in ashy, wet or oily environments. Failure to do so may shorten the life of this product and may cause injury to its user(s).

Please keep this product as far away from radio frequency interruption area as possible. This is not an outdoors product. Exposing this product to the elements may cause damages to the product and may cause bodily harm to its users. Please do not use alcohol, petroleum, benzene or thinner-based solution to clean this product. We recommend wiping this product with a damp cloth.

Warranty Information

This product is warranted to be free from defects in material and workmanship for a warranty period of 1-YEAR. If a product proves to be defective in material or workmanship during the warranty period, we will repair or replace the product with a like product at our sole option. Replacement product or parts may include remanufactured or refurbished parts or components. This warranty is valid only for the first purchaser with a valid proof of purchase.

The warranty does not cover:

1. Any product with defaced, modified or removed serial number.

2. Damage, deterioration or malfunction resulting from:

- » Accident, misuse, negligence, natural hazards including: fire, water, lightning and/or other acts of nature.
- » Any unauthorized modifications not complying with the standard product or failure to follow instructions supplied with the product.
- » Repair or attempted repair by unauthorized personnel.
- » Shipping damage; please consult with your point of purchase if the product is suspected to have been damaged during shipping.
- » Removal or installation of the product.
- » Causes external to the product, such as absense of electrical grounding, power fluctuation, failure and/or power spikes.
- » Normal wear and tear.
- » Any other cause non related to a product defect.

Troubleshooting

Please visit our website : www.rosewill.com

FCC Statement on CLASS B

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
» THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND
» THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

WARNING: A SHIELDED-TYPE CORD IS REQUIRED IN ORDER TO MEET FCC OMISSION LIMITS AND ALSO TO PREVENT INTERFERENCE TO THE NEARBY RADIO AND TELEVISION RECEPTION. IT IS ESSENTIAL THAT ONLY THE SUPPLIED CORD BE USED.

Mandatory repair charges are required for the following conditions, even within the guarantee period:

- (1) Malfunction or damage is due to misuse or improper alteration or repair.
- (2) Malfunction or damage is caused by the movement or fall during installation after the purchase.

- (3) Malfunction or damage is caused by a fire, salt, gas, earthquake, lightning, wind, water or other natural calamities, or abnormal voltage.
- (4) The manual is not presented.
- (5) Date of purchase, customer's name, name of the shop are not filled in or are altered.
- (6) Malfunction or damage is caused by other devices connected to this product.

ALL BRAND NAMES, TRADEMARKS AND LOGOS ARE THE PROPERTIES OF THEIR RESPECTIVE OWNERS.

Thank you for purchasing a quality Rosewill Product.
Please register your product at : www.rosewill.com/ for complete warranty information and future support for your product.